Emergency Radio Instructions

Applicable only during pinbox operations.

Upon arrival, your vessel was provided with an RST emergency radio for use while berthed alongside RST.
This device is intended solely for emergency situations. To ensure its effective operation and the safety of all personnel involved, the following instructions must be strictly observed:



1. Responsibility during operations
During operations the designated crew member is responsible for communication with the terminal and shall always carry the emergency radio.

2. Use of the emergency alarm
The alarm button shall only be activated in the event of an actual emergency requiring the immediate attention of the terminal.

Upon activation of the alarm:

- All crane operations will be stopped immediately for a short period.
- The vessel's name will be displayed in the RST control room.
- RST Vesselplanning will contact the vessel to assess the situation and determine whether the alarm relates to an actual emergency or a false activation.
- In the event of a false alarm operations will resume as soon as practicable.

3. Prohibited use
The emergency radio shall not be used for operational matters or routine communication. This includes, but is not limited to, reporting twistlock issues operations-related concerns, or other non-emergency situations.

4. Functionality of the device
The emergency radio is equipped with an alarm function only. It is not a communication device and does not provide voice contact between the vessel and crane operators or terminal personnel.

Compliance with these instructions is essential to ensure the effectiveness of the emergency response system and the safety of all personnel working on board and ashore.

Contact details RST

Pre- Arrival/ Berth **Primair Contactperson RST**	**Berthplanning** **Vesselplanning**
Phone number	**+31 10 294 2451/ 2453/ 2455**
E-mail adress	**Berthplanning@rstbv.nl** **Vesselplanning@rstbv.nl**
RST Operational Shiftmanager	**Shiftmanagers-dg@rstbv.nl** **+31 10 2946838**
Security City Terminal	**security@rstbv.nl** **+31 10 2942528**
Emergency number	**ALWAYS CONTACT SECURITY CITY TERMINAL** **+31 10-2942527**